

LENS ATTACHMENTS

FISHEYE LENS:



FC-E8 FISHEYE CONVERTER LENS

Approximately 183 degree coverage. Can be used as a full frame or circular image lens.

PROD.#: 25101 **UPC CODE:** 018208251018



with converter set to circular



with converter set to full frame fisheye

For use with Coolpix 4300 (with UR-E4 adapter), 5000 (with UR-E6 adapter), & 4500

TELEPHOTO LENSES



TC-E15ED 1.5x TELE CONVERTER LENS

Increases focal length of lens by 1.5 times with Nikon's high quality ED glass.

PROD.#: 25107 **UPC CODE:** 018208251070

For use with Coolpix 5700 (with UR-E8 adapter)



without converter



with converter



TC-E2 2x TELE CONVERTER LENS

Doubles focal length of lens.

PROD.#: 25102 **UPC CODE:** 018208251025

For use with Coolpix 4300 (with UR-E4 adapter), 5000 (with UR-E6 adapter), & 4500



without converter



with converter



TC-E3ED 3x TELE CONVERTER LENS

Triples focal length of lens with Nikon's high quality ED glass.

PROD.#: 25103 **UPC CODE:** 018208251032

For use with Coolpix 4300 (with UR-E4 adapter), 5000 (with UR-E6 adapter), & 4500



without converter



with converter

WIDE ANGLE LENSES



WC-E63 WIDE-ANGLE CONVERTER LENS

Offers wide-angle coverage.

PROD.#: 25104 **UPC CODE:** 018208251049

For use with Coolpix 4300 (with UR-E4 adapter) & 4500



without converter



with converter



WC-E68 WIDE-ANGLE CONVERTER LENS

Offers wide-angle coverage.

PROD.#: 25105 **UPC CODE:** 018208251056

For use with Coolpix 4300 (with UR-E4 & UR-E7 adapter), 4500 (with UR-E7 adapter) & 5000 (with UR-E5 adapter)



without converter



with converter



WC-E80 WIDE-ANGLE CONVERTER LENS

Offers wide-angle coverage.

PROD.#: 25106 **UPC CODE:** 018208251063

For use with Coolpix 5700 (with UR-E8 adapter)



without converter



with converter

STEP-DOWN RINGS:



UR-E4 CONVERTER ADAPTER

Used to connect Converter Lenses to the Coolpix 4300

PROD.#: 25164

UPC CODE: 018208251643



UR-E5 CONVERTER ADAPTER

Used to connect the Wide Angle WC-E68 Converter Lens to the Coolpix 5000

PROD.#: 25170

UPC CODE: 018208251704



UR-E6 CONVERTER ADAPTER

Used to connect Converter Lenses to the Coolpix 5000 except Wide Angle Converter WC-E68

PROD.#: 25171

UPC CODE: 018208251711



UR-E7 CONVERTER ADAPTER

Used to connect the Wide Angle WC-E68 Converter Lens to the Coolpix 4300 & 4500

PROD.#: 25172

UPC CODE: 018208251728



UR-E8 CONVERTER ADAPTER

Used to connect the Wide-Angle WC-E80 and Tele Converter TC-E15ED Lenses to the Coolpix 5700

PROD.#: 25186

UPC CODE: 018208251865

LENS HOODS:

HN-E5000 LENS HOOD

Reduces stray light & minimizes lens flare. For use with the Coolpix 5000.

PROD.#: 25174

UPC CODE: 018208251742

For use with Coolpix 5000



HR-E5700 LENS HOOD

Reduces stray light & minimizes lens flare. For use with the Coolpix 5700.

PROD.#: 25185

UPC CODE: 018208251858

For use with Coolpix 5700



LENS FILTER SETS:

FILTER SET (28mm)

Set of four 28mm filters (UV, Circular Polarizer, Neutral Density 4 and Neutral Density 8) in a handy wallet. For use with the Coolpix 4500.

PROD.#: 5363 **UPC CODE:** 018208053636

For use with Coolpix 4500



FILTER SET (46mm)

Set of four 46mm filters (UV, Circular Polarizer, Neutral Density 4 and Neutral Density 8) in a handy wallet. Requires UR-E5 Converter Adapter for use with the Coolpix 5000.

PROD.#: 5508 **UPC CODE:** 018208055081

For use with Coolpix 5000



Filter Effects

Name	Color	Exposure Factor	
UV	Transparent	1	Absorbs ultra-violet rays without increase of exposure, thereby preventing haziness and foggy effects in distant landscapes. Constant use of this filter is recommended as a lens protector.
Circular Polarizer (C-PL)	Gray	2	Removes or reduces reflections from non-metallic surfaces, darkens blue sky while increasing color saturation, penetrates haze. Simply rotate the filter in its mount until the optimum effect is obtained.
Neutral Density 4	Light Gray	4	Neutral Density (ND) filter is used for reducing amount of light without changing color rendition. ND4 transmits 25% of the light. ND8 12.5%
Neutral Density 8	Medium Gray	8	

MH-53 BATTERY CHARGER

MH-53 Battery Charger allows you to recharge an EN-EL1 Li-ion Rechargeable Battery. For use with the Coolpix 4300, 4500, 5000, 5700.



PROD.#:	UPC CODE:
25196	018208251964

EN-EL1 RECHARGEABLE BATTERY

This Li-ion rechargeable Lithium battery works with the MH-53 Battery Charger. For use with the Coolpix 4300, 4500, 5000, 5700.



PROD.#:	UPC CODE:
9895	018208098958

EN-EL2 RECHARGEABLE BATTERY

The EN-EL2 Rechargeable Lithium Battery is compatible with the MH-60 Battery Charger. For use with the Coolpix 2500.



PROD.#:	UPC CODE:
9904	018208099047

MH-60 BATTERY CHARGER

MH-60 Battery Charger allows you to recharge an EN-EL2 Li-ion Rechargeable Battery. For use with the Coolpix 2500.



PROD.#:	UPC CODE:
25182	018208251827

EH-53 AC ADAPTER

The EH-53 AC Adapter is for operating selected Coolpix digital cameras from an AC power source. For use with Coolpix 4300, 4500, 5000, 5700



PROD.#:	UPC CODE:
25183	018208251834

EH-60 AC ADAPTER

Allows you to power your Coolpix direct from an AC outlet. Ideal for long shooting situations or for downloading images to a computer. For use with the Coolpix 2500.



PROD.#:	UPC CODE:
25176	018208251766

MB-E5000 BATTERY PACK

Allows the use of six AA batteries for extended power. Enhances camera handling for composing vertical images and includes a vertical firing release for a more comfortable feel. For use with Coolpix 5000.



PROD.#:	UPC CODE:
25173	018208251735

MB-E5700 BATTERY PACK

Allows the use of six AA batteries for extended power. Enhances camera handling for composing vertical images and includes a vertical firing release for a more comfortable feel. For use with Coolpix 5700.



PROD.#:	UPC CODE:
25184	018208251841

Prod. #25067 is shown



(External flash and camera sold separately)

SK-E900 EXTERNAL MULTI-FLASH BRACKET UNIT

When used with the Coolpix 4500 digital camera, the SK-E900 allows the use of off-camera flash. Add up to five additional speedlights (SB-80DX, SB-50DX, SB-30, SB-28DX, SB-28, SB-26, SB-25, SB-24, SB-22 or SB-22s). Camera meters the brightness of the subject and adjusts the output of the built-in and external flash automatically. Equipped with two synch flash terminals for additional multi-flash effects.

PROD.#:	UPC CODE:
25067	018208250677



AS-E900 EXTERNAL MULTI-FLASH ADAPTER (without bracket)

For use with Coolpix 4500.

PROD.#:	UPC CODE:
25068	018208250684



MACRO COOL-LIGHT SL-1

Provides Coolpix users easy macro shooting without the need for special lighting equipment. Works with eight, high-luminance white LED bulbs to give a lightweight, full-surround illumination. For use with Coolpix 5000 (requires UR-E6 adapter), 4300 (requires UR-E4 adapter), and 4500.

PROD.#:	UPC CODE:
25189	018208251896



HL-CP11

For use with the Coolpix 2000.

PROD.#:	UPC CODE:
25192	018208251926



HL-E2500

For use with the Coolpix 2500.

PROD.#:	UPC CODE:
25178	018208251780



HL-E885

For use with the Coolpix 4300.

PROD.#:	UPC CODE:
25165	018208251650



HL-CP10

For use with the Coolpix 4500.

PROD.#:	UPC CODE:
25188	018208251889



HL-E5000

For use with the Coolpix 5000.

PROD.#:	UPC CODE:
25175	018208251759

LCD HOODS

Prevents bright light from hitting the LCD. Allows for better viewing in bright light situations.



PROD.#:
5519

UPC CODE:
018208055197

For use with Coolpix 2000/4300



PROD.#:
9905

UPC CODE:
018208099054

For use with Coolpix 2500



PROD.#:
5380

UPC CODE:
018208053803

For use with Coolpix 4500



PROD.#:
5479

UPC CODE:
018208054794

For use with Coolpix 5000



PROD.#:
5523

UPC CODE:
018208055234

For use with Coolpix 5700

COOLPIX CASES

Attractive carrying cases designed specifically to house and protect Coolpix Digital Cameras

Camera not included



ES-E28 SLIDE/FILM COPYING ADAPTER

By attaching this adapter to your camera, you can shoot 35mm format positive or negative film. For use with the Coolpix 4300 (requires UR-E4 adapter), 5000 (requires UR-E6 adapter) and 4500.

PROD.#:	UPC CODE:
25147	018208251476



MC-EU1 REMOTE CORD

Permits remote shutter release of the camera. Also enables zoom setting, interval shooting, playback and LCD illumination on/off. You can also confirm information such as the set mode and the number of frames to be captured. For use with the Coolpix 4300, 4500, 5000, 5700.

PROD.#:	UPC CODE:
25146	018208251469



PC CARD ADAPTER

Allows CompactFlash™ cards to be used in a laptop computer with PC Card slot. When inserted in the PC Card Adapter, CompactFlash™ memory can be used as an ATA memory card (PC Card standard). For use with all Coolpix digital cameras.

PROD.#:	UPC CODE:
25078	018208250783



USB COMPACTFLASH™ CARD READER

Allows high speed downloads directly from the CompactFlash™ Card through the USB port on your Macintosh or Windows PC without tying up your camera. For use with all Coolpix digital cameras.

PROD.#:	UPC CODE:
25111	018208251117



NIKON SCHOOL VIDEOS

Nikon School presents "The Nikon Guide to Coolpix Digital Photography". Hosted by Bob Krist and featuring digital consultant Helene DeLillo, this video covers everything from the fundamentals of digital photography to basic image management, manipulation and printing techniques. For use with all Coolpix digital cameras.

PROD.#:	UPC CODE:
5387	018208053872



COOLPACK II: THE DIGITAL PHOTOGRAPHER'S SURVIVAL KIT

Rugged carrying case, USB CompactFlash™ Card Reader and set of four 28mm filters in a handy wallet; includes UV, Circular Polarizer, Neutral Density 4, Neutral Density 8. For use with Coolpix 4500.

PROD.#:	UPC CODE:
9868	018208098682

Flash Card Capacities*:

	8MB	16MB	32MB	64MB	96MB
2560 x 1920 (5 Megapixel)					
HI-TIFF	0	1	2	4	6
Fine*	3	7	12	25	38
Normal*	6	14	24	50	76
Basic*	12	28	48	100	152
2272 x 1704 (4 Megapixel)					
HI-TIFF	0	1	2	4	6
Fine*	4	8	16	32	48
Normal*	8	16	32	64	96
Basic*	16	32	64	128	192
2048 x 1536 (3 Megapixel)					
HI-TIFF	0	1	3	6	10
Fine*	5	10	20	40	61
Normal*	10	20	40	81	121
Basic*	19	38	79	159	239
1600 x 1200 (2 Megapixel)					
Fine*	8	16	32	64	96
Normal*	16	32	64	129	192
Basic*	32	64	128	258	386
1280 x 960					
Fine*	12	24	48	96	144
Normal*	24	47	99	188	282
Basic*	43	86	177	344	516
1024 x 768					
Fine*	19	38	76	159	239
Normal*	39	76	146	311	466
Basic*	78	146	292	590	885
640 x 480					
Fine*	48	96	182	392	588
Normal*	91	182	222	734	1101
Basic*	161	222	444	1302	1952

*In Fine, Normal and Basic modes images are captured using JPEG compression. The calculated number of images is only an estimate and will vary due to the nature of JPEG compression.

Coolpix Accessories:

		Compatible with Coolpix Model:						
Part #	Description	2000	2500	4300	4500	5000	5700	MSRP
25101	Fisheye Converter Lens FC-E8			UR-E4*	●	UR-E6*		\$219.95
25107	1.5x Tele Converter Lens TC-E15ED						UR-E8*	\$209.95
25102	2x Tele Converter Lens TC-E2			UR-E4*	●	UR-E6*		\$149.95
25103	3x Tele Converter Lens TC-E3ED			UR-E4*	●	UR-E6*		\$259.95
25104	Wide-Angle Converter Lens WC-E63			UR-E4*	●			\$149.95
25105	Wide-Angle Converter Lens WC-E68			UR-E4* +UR-E7	UR-E7*	UR-E5*		\$179.95
25106	Wide Angle Converter Lens WC-E80						UR-E8*	\$199.95
25164	Converter Adapter UR-E4			●				\$9.95
25170	Converter Adapter UR-E5					●		\$12.95
25171	Converter Adapter UR-E6					●		\$12.95
25172	Converter Adapter UR-E7			●	●			\$12.95
25186	Converter Adapter UR-E8						●	\$15.95
5363	28mm Filter Set				●			\$69.95
5508	46mm Filter Set					UR-E5*		\$69.95
25174	Lens Hood HN-E5000					●		\$19.95
25185	Lens Hood HR-E5700						●	\$29.95
9895	EN-EL1 Li-ion Rechargeable Battery			●	●	●	●	\$34.95
25196	MH-53 Battery Charger			●	●	●	●	\$24.95
25183	EH-53 AC Adapter	●		●	●	●	●	\$24.95
9904	EN-EL2 Li-ion Rechargeable Battery		●					\$34.95
25182	MH-60 Battery Charger		●					\$21.95
25176	EH-60 AC Adapter		●					\$35.95
25173	Battery Pack MB-E5000					●		\$139.95
25184	Battery Pack MB-E5700						●	\$169.95
25067	Multi Flash Bracket Unit SK-E900				●			\$69.00
25068	Multi Flash Adapter AS-E900				●			\$41.00
25189	MACRO COOL-LIGHT SL-1			UR-E4*	●	UR-E6*		\$99.95
25178	LCD Hood HL-E2500		●					\$9.95
25165	LCD Hood HL-E885			●				\$27.95
25175	LCD Hood HL-E5000					●		\$27.95
25188	LCD Hood HL-CP10				●			\$32.95
25192	LCD Hood HL-CP11	●						\$14.95
5519	Case for Coolpix 2000 and 4300	●		●				\$11.95
9905	Case for Coolpix 2500		●					\$9.95
5380	Case for Coolpix 4500/990/995				●			\$19.95
5479	Case for Coolpix 5000					●		\$29.95
5523	Case for Coolpix 5700						●	\$29.95
25147	Slide Copying Adapter ES-E28			UR-E4*	●	UR-E6*		\$69.95
25146	Remote Release Cord MC-EU1			●	●	●	●	\$99.95
25078	PC Card Adapter EC-AD1	●	●	●	●	●	●	\$15.95
25111	USB CompactFlash™ Card Reader	●	●	●	●	●	●	\$59.95
9868	CoolPack II				●			\$119.95
5387	Nikon School Presents The Nikon Guide to Coolpix Digital Photography	●	●	●	●	●	●	\$30.00

* accessory is compatible with camera using indicated converter adapters.